

LOCATION: Pignata Road – PIG 2 Gate

VMP #: 057

UHF: 10

REMEMBER!! BEFORE ENTERING ANY GATE ANNOUNCE ON THE TWO WAY RADIO YOU ARE APPROACHING THE GATE AND TURN ON YOUR FLASHING LIGHTS ON APPROACH.

WHEN LEAVING SITE CALL UP AND REMEMBER TO SWITCH OFF FLASHING LIGHTS BEFORE ENTERING PUBLIC ROADS (FINES APPLY)



ACCESS INSTRUCTIONS:

- ALL DRIVERS MUST PROCEED WITH CAUTION AND ADHERE TO THE QLD ROAD RULES AT ALL TIMES
 - ONLY USE DESIGNATED ACCESS POINTS
 - ALL VEHICLE DRIVERS MUST FOLLOW THE INSTRUCTIONS OF THE WORKS SUPERVISOR
 - NO REVERSING OF VEHICLES ON ANY ROADS WITHOUT APPROPRIATE CONTROLS
 - NO PARKING OR STOPPING ON ANY ROADS UNLESS IN AN EMERGENCY
 - ALL HEAVY VEHICLES MUST BE INSPECTED PRIOR TO EXITING THE SITE FOR LOOSE, FOREIGN DEBRIS AND TARP CORRECTLY FASTENED
- VMP TO BE ENFORCED BY:
- ALL PERSONNEL WORKING AT THE SITE AND DELIVERIES SCHEDULED TO COME TO THIS SITE, ARE TO BE PROVIDED WITH A COPY OF THIS VMP

OTHER SITE SPECIFIC INSTRUCTIONS: UHF Channels for gates and work areas to remain on display at entry points

POSITIVE COMMS REQUIRED PRIOR PROCEEDING INTO A WORK AREA

SITE SUPERVISOR:

Chris Smart

0438 529 097

SUPERINTENDENT:

Peter Barnes

0437 646 073

Prepared By: Felicity Leis

Reviewed By: Rob Owen

Approved By: Peter Barnes